

FCB update tool Manual

Target Model

- FCB-ER8300
- FCB-CR8300


Necessary Machinery

- Windows PC
- FCB(ER8300/CR8300)
- USB cable(Micro-USB(A-MicroB) cable)
- User update firmware file (dat file)

Support OS


- Windows 8、8.1 (Enterprise/Professional)
 - Windows 7 (Enterprise/Professional)
 - Windows Vista (Business)
- 32bit/64bit、OS Laung.: Jpn/Eng

GUI




Install & Activation method

1. Unpack the zip and unzip its contents on your system.
2. Copy “User update firmware file (dat file)” to the folder which you unzipped file.(ex : FCBUpdateTool_v.1.1.9.1081).




※Notice

1. The file name begins with “FirmwareData”.
2. The file extension is “dat”.
3. Put the above file in the same folder and please, check it.
 - * If the pre condition(1.-3.) is not satisfied, you can not start Firmware update.



3. Connect USB cable to the FCB.(MASS STORAGE mode)
4. Run 「FCBUpdateTool.exe」 in your folder.



Install & Activation method

5. Push “Next” button following the guidance of GUI, and proceed User update.
It's complete by status of “Finish the update”, and then push “Finish” button.

