

How to use FCB Update Tool

Equipment for Update


- Windows PC
- FCB Camera(ER8300, ER8550)
- USB Cable(Micro-USB(“typeA” to “MicroB”) Cable)
- Firmware File for Update(dat file)

Supported OS

- Windows 8、8.1 (Enterprise/Professional)
- Windows 7 (Enterprise/Professional)
- Windows Vista (Business)

32bit/64bit, OS Language: Japanese & English

Updater




Progress

Explanation about operation/error etc.

Progress Bar

Progress Indicator

Coming operation : 

On going operation : 

Finished operation : 


Update Information

Operation Start Button



Operation Finish Button

How to Install & Run


1. Extract and Open zip file which include FCB Update tool.
2. Put Firmware File into the folder where FCB Update tool is located.



3. Connect FCB camera and PC by using jig & USB cable.
Check that FCB camera is recognized as “mass storage device” at PC side.
4. Run “FCBUpdateTool.exe”



5. According to guide of the tool. press “Next”.
Then version up procedure will go on to next step one by one.



6. Update is completed when status changes “Finish the update”.
Press “Finish”, then you can close updater.